

SIRCO Bestellnummern

Standardanwendungen - Frontantrieb - 3 oder 4 Pole

Baugröße (A)	Polzahl	Grundgerät ⁽¹⁾	Griff für Direktantrieb	Externer Griff	Achse für externen Antrieb	Hilfsschalter	Klemmenabdeckung	Anschlussabdeckung
125 A	3 P	2600 3014	Typ B1 Schwarz 2699 5042 ⁽²⁾				3 P 2694 3014 ⁽³⁾ 4 P 2694 4014 ⁽³⁾	3 P 2698 3012 ⁽³⁾ 4 P 2698 4012 ⁽³⁾
	4 P	2600 4014						
160 A	3 P	2600 3017	Rot 2699 5043					
	4 P	2600 4017						
200 A	3 P	2600 3021					3 P 2694 3021 ⁽³⁾ 4 P 2694 4021 ⁽³⁾	3 P 2698 3020 ⁽³⁾ 4 P 2698 4020 ⁽³⁾
	4 P	2600 4021						
250 A	3 P	2600 3026		Typ S2 Schwarz IP65 1421 2111 ⁽²⁾ Schwarz IP65 1423 2111	200 mm 1400 1020 320 mm 1400 1032 ⁽²⁾ 500 mm 1400 1050			
	4 P	2600 4026						
315 A	3 P	2600 3032	Typ B2 Schwarz 2699 5052 ⁽²⁾	Rot IP65 1424 2111				
	4 P	2600 4032						
400 A	3 P	2600 3041	Rot 2699 5053				3 P 2694 3051 ⁽³⁾ 4 P 2694 4051 ⁽³⁾	3 P 2698 3050 ⁽³⁾ 4 P 2698 4050 ⁽³⁾
	4 P	2600 4041						
500 A	3 P	2600 3051						
	4 P	2600 4051						
630 A	3 P	2600 3064						
	4 P	2600 4064						
800 A	3 P	2600 3081				1. Kontakt ÖS 2699 0031 2. Kontakt ÖS 2699 0032		
	4 P	2600 4081						
1000 A	3 P	2600 3099						3 P 2698 3080 ⁽³⁾ 4 P 2698 4080 ⁽³⁾
	4 P	2600 4099						
CD 1250 A	3 P	2600 3119		Typ S4 Schwarz IP65 1443 3111 ⁽²⁾ Rot IP65 1444 3111	200 mm 1401 1520 320 mm 1401 1532 ⁽²⁾ 400 mm 1401 1540			
	4 P	2600 4119						
1250 A	3 P	2600 3121	Typ C2 Schwarz 2799 7012 ⁽²⁾					
	4 P	2600 4121						
1600 A	3 P	2600 3161	Rot 2799 7013					3 P 2698 3120 ⁽³⁾ 4 P 2698 4120 ⁽³⁾
	4 P	2600 4161						
1800 A	3 P	2600 3181						
	4 P	2600 4181						
2000 A	3 P	2600 3200						
	4 P	2600 4200						
2500 A	3 P	2600 3250		Typ V2 Schwarz IP65 2799 7136 ⁽²⁾ Rot IP65 2799 7134	200 mm 2799 3015 320 mm 2799 3018 ⁽²⁾ 450 mm 2799 3019			3 P 2698 3200 ⁽³⁾ 4 P 2698 4200 ⁽³⁾
	4 P	2600 4250						
3200 A	3 P	2600 3320						
	4 P	2600 4320						
4000 A	3 P	2600 3401	Typ V0 Schwarz 2799 7072 ⁽²⁾	Typ V0 Schwarz IP65 2799 7155 ⁽²⁾				
	4 P	2600 4401						
5000 A	3 P	2600 3500				1. / 2. Kontakt ÖS ab Werk		
	4 P	2600 4500						

(1) Gerät verfügbar im Gehäuse (siehe "Vorortschalter im Gehäuse", Seite 446).

(2) Standard.

(3) Oben oder unten.