RB100 RB400 RB500 RB700 RB900





General Description

The RB Series is a high performance budget friendly temperature controller. Save space and save money with RB series that gives outstanding control capability and comprehensive functions incorporated into a slim body case.

Applications include various plastic machines (extrudes, injection machine, etc), electric furnaces, semiconductor, food processing,



Features


environmental chambers and many others.

- ☆ Easy-to-read with large 11-segment LCD display
- ☆ The depth of 60mm
- ☆ Sampling 0.25 sec
- ☆ Brilliant II PID control
- ☆ Start-up tuning and Autotuniung

Panel space saving: 60mm depth


The RB Series has very short depth.

The series was designed with a mounting bracket that allows close horizontal mounting of as many as six units. .




Easy-to-read with large 11-segment LCD display

So bright and so large it is easy to read from a greater distance.



Numerous inputs and outputs




- The number of digital outputs is limited depending on the model and specifications.
- Analog Output is not available for some control types and models
 On the RB100, either communication or digital input can be selected.

Store up to 4 Set Values


Set value changeover is also possible by digital input.






Timer Function

Control starts after the timer time elapses.



Control is performed during the timer time and stops after the timer time elapses.






Features

Simple program control


Simple program control using a timer function / setting change proportion limiter



Calculates optimum PID values to stabilize control faster than ever


The improved autotuning algorithm calculates optimum PID values that shortens the time to reach stable control at the set value as well as eliminating overshoot/undershoot.

The new PID algorithm also suppress overshoot/undershoot against external disturbance.



Easy Fine tuning with 6-level of control response adjustment

After the PID values have been autotuned, the Fine tuning (FT) function allows the operator to adjust the control response speed with a 6-level adjustment parameter (-3 to +3) without changing PID value.




-3 to -1: Faster response Slower respon Function OFF

Startup tuning

Startup tuning eliminates time required for conventional autotuning as it calculates optimum PID values by temperature characteristics at start up.

It is useful in applications which require a long time for conventional autotuning.

The timing of activation of start-up tuning can be selected from at power-up, at setpoint change, and at power-up/setpoint change. It is also settable to Only-once or always-ON.




- Startup tuning function can be set ON/OFF.
 Heater power needs to be turned on simultaneously with or before turning on power to the
- temperature commoner.

 If startup tuning does not calculate suitable PID values due to characteristics of application, use Autotuning function.

Easy parameter setup via USB loader port

The RB series has a standard loader port to connect to a PC USB port via COM-K2 (USB communication converter).


Using Win-UCI software on the PC, parameter settings can be easily saved on the PC in CSV format, and the same parameter settings are easily copied to other controllers.



COM-K2-1 (With loader communication cable) COM-K2-N(Without loader communication cable)

PLC Communication Protocol Converter <u>: COM-JE</u>

A communication protocol converter becomes a Master Unit to PLC, and automatically stores temperature data into registers in a PLC. This enables easy handling of temperature control system to the exiting PLC system is available.





Specifications

Input

Input

a) Temperature input group

: K, J, R, S, B, E, T, N (JIS/IEC), PLII (NBS), W5Re/W26Re (ASTM) Thermocouple

 Influence of external resistance : Approx. 0.25μV/Ω •Input break action : Up-scale / Down-scale (Selectable)

RTD: Pt100 (JIS/IEC), JPt100 (JIS)

•Influence of input lead resistance : Approx. $0.02[\%/\Omega]$ of reading

Maximum 10Ω per wire
Input break action : Up-scale

b) Voltage • current input group

Voltage: 0 to 1V DC, 0 to 5V DC, 1 to 5V DC, 0 to 10V DC
•Input break action: Uncertain (indicates a value around 0V)
Current: 4 to 20mA DC, 0 to 20mA DC

Inputs is selectable within each group

Sampling Time

0.25 sec

Input Digital Filter

0 to 100 sec (OFF when 0 is set.)

Temperature input : -1999(-199.9) to +9999(999/9)°C(°F) Voltage/Current input : -span to +span

Performance

Measuring Accuracy

a) Thermocouple

Type: K, J, T, E, N

Less than -100°C (-148°F) : ±(2.0°C[±3.6°F] + 1 digit)
-100 to 500°C (-148 to 932°F) : ±(1.0°C [±1.8°F] + 1 digit)

More than 500°C (932°F): ±(0.2% of Reading + 1 digit) Type: N, S, R, PLII, W5Re/W26Re

Less than 0°C (32°F): ±(4.0°C[±7.2°F] + 1 digit) 0 to 1000°C (-148 to 1832°F): ±(2.0°C[±3.6°F] + 1 digit)

More than 1000°C (1832°F) : ±(0.2% of Reading + 1 digit)

Less than 400°C (752°F): ±(70°C [±126°F] + 1 digit)

400 to 1000°C (752 to 1832°F): ±(2°C[±3.6°F] + 1 digit) More than 1000°C (1832°F): ±(0.2% of Reading + 1 digit)

Less than 200°C (392°F) : \pm (0.4°C [\pm 0.7°F] + 1 digit) More than 200°C (392°F) : \pm (0.2% of Reading + 1 digit)

c) DC voltage and DC current $\pm (0.2\% \text{ of span} + 1 \text{ digit})$

•Close horizontal mounting error

±2°C (3.6°F) [Less than -100°C (-146°F) input : ±3.5°C (6.3°F)]

Insulation Resistance

More than $20M\Omega$ (500V DC) between measured terminals and ground More than 20MΩ (500V DC) between power terminals and ground

Dielectric Strength

1000V AC for one minute between measured terminals and ground 1500V AC for one minute between power terminals and ground

Setting

SV limiter

Scaling low to scaling high (High/Low individual setting

1(0.1) to span per Time

(Time: 1 minute/1 hour (Selectable) Up/Down individual setting)

Number of SV: 4 points (Default: 1 point) SV selecting method : Front key, Communication, Digital input (External contact input)

Timer function

Timer setting: 0 min 01 sec to 99 min 59 sec or 0 hr 01 min to 99 hr 59 min (selectable)

- Function
 1: Control starts after the timer time elapses.
 2: Control is performed during the timer time and stops after the timer

time elapses.

3: Link function from SV1 to SV4
(After the timer time elapses, control is continued using SV4.)

4: Link function from SV1 to SV4
(After the timer time elapses, control is stopped.)
Repeat: 0 to 9999 (Continuous when when 9999 is set.)

Setting data lock Lock level : 1 to 10 level (0 : No lock)

Control

Control Method

a) PID control

• P, PI, PD, ON/OFF control selectable

Direct action/Reverse action is selectable
 Heat/Cool type PID control

Autotuning Method

a) For PID control (Direct action/Reverse action)
b) For Heat/Cool PID control (For extruder, air cooling type)
c) For Heat/Cool PID control (For extruder, water cooling type)

d) For Heat/Cool PID control

Startup tuning

The condition to activate Startup Tuning is selectable among a) to g)

a) At power-on and stop-to-run, one-time tuning

b) At SV change, one-time tuning c) At power-on, stop-to-run and SV change, one-time tuning

d) At every power-on and stop-to-run

e) At every SV change

At every power-on, stop-to-run and SV change

g) Function off

Fine tuning

Setting range: -3 to +3 (6 levels, OFF when set to 0.)
-3 to -1: Faster response

Slower response Function OFF

Major Setting Range

Integral time: Derivative time:

Set value

Same as input range. 0(0.0) to input span (Temperature input) Proportional band:

• When 0.1°C (°F) resolution, within 999.9°C (°F) 0.0 to 1000.0% of span (Voltage, Current input)

(ON/OFF control when P = 0) Differential gap at ON/OFF control

(High/Low individual setting):
Temperature input: 0(0.0) to 100 (100.0) (°C,°F)
Voltage/Current input: 0.0 to 10.0% of span
0 to 3600sec (P + D action when I = 0)
0 to 3600sec (P + I action when D = 0)

Cool-side proportional band : 1 to 1000% of heat side proportional band 1 to 100% of heat side proportional band (Integral action is OFF when ARW = 0) -10 (-10.0) to 10 (10.0) °C (°F) (Temperature input) -10.0 to +10.0% of span (Voltage, Current input) • Minus setting: Overlap Anti-Reset Windup(ARW) Deadband/Overlap:

Derivative time action select : 0 : PV derivative, 1 : Deviation derivative Output limiter : -5.0 to +105.0% (PID control) (High/Low individual setting)

0.0 to 105.0%Heat/Cool type PID control

(Only limiter high)

(Heat side/Cool side individual setting) Proportional cycle time: 0.1sec, 0.25sec, 0.5sec, 1 to 100 sec

Output limiter low to Output limiter high Auto/Manual transfer action selection With bumpless/Without bumpless

Control output

Current output :

Voltage output :

Manual output:

Form A contact, 250V AC 3A (resistive load)
• Electric life: 100,000 cycles or more Relay output: Voltage pulse output :

(Load resistance : more than 600Ω <less than 20mA>) When OUT2 is no use, load resistance is more than 300Ω <less than 40mA>.

Soud Ress than 40mAs. See page 1-11 "Maximum number of digital outputs (DO) by combinations of output (OUT1 and OUT2) 4 to 20mA DC, 0 to 20mA DC (Load resistance: less than 500Ω)

SSR (Triac) output: Rated current : 0.5A

(Ambient temperature : Less than 40°C) 0 to 5V DC, 1 to 5V DC, 0 to 10V DC (Load resistance : More than 1k Ω) Output impedance : Less than 0.1Ω

Open collector output:

Sink type Load current : Less than 100mA Load voltage : Less than 30V DC Minimum load current : 0.5mA ON voltage: Less than 2V

(at maximum load current)

Power OFF leakage current : Less than 0.1mA

RB 02E



Specifications

Event (Alarm) Output

(Optional)

Number of Event

Up to 4 points (Event 1 to 4) (RB100 : Up to 3 points, Heat/Cool type : Up to 2 points)

Event Туре

Deviation High, Low, High/Low¹¹, Band, Process High, Low Set value High, Low Control Loop Break Alarm (LBA) Heater break alarm (HBA).

Output of the communication monitoring result, RUN status monitor

**Tu: Two types of alarm settings are field-selectable.

1. Independent high and low settings.

2. Common high/low setting

(Factory setting, unless specified in alarm code

when ordering)

Setting range

Deviation:

- (Input span) to + (input span)
Differential gap: 0 to input span
Same as input range
Differential gap: 0 to input span
MV value, FBR valued:
-5.0 to +105.0%
Control loop break alarm (LBA)

LBA time: 0 to 7200 sec. (OFF by setting zero) LBA deadband : 0 to input span

Other Functions

a) Hold/Re-hold actionHold action is activated at power-on and stop-to-run.

Re-hold action is activated at power-on, stop-to-run, and the control set value change.

b) Alarm output ON/OFF at stop mode is selectable.
c) Energized/de-energized action is configurable.
d) Differential gap: 0 (0.0) to span
e) Delay timer: 0 to 600 sec

f) Interlock (latch) function is configurable.

Heater Break Alarm Number of CT Input:

2 points CTL-6-P-N (30A), CTL-12-S56-10L-N (100A) • Selectable CT Input type:

Accuracy $\pm (5\%$ of input value + 1 digit) or 2A (whichever is larger) 0.0 to 100.0A

Display range : Delay times : 0 to 255 times

Output

Relay contact output, Form a contact, 250V AC 1A (Resistive load)

Analog Retransmission Output (Optional)

Number of Outputs

1 point

Output types
Measured value (PV), Set value (SV), Manipulated output value (MV)

4 to 20mA DC, 0 to 20mA DC Current output :

(Load resistance : Less than 600Ω) Continuous voltage output : 0 to 1V DC, 0 to 5V DC, 1 to 5V DC, 0 to 10V DC (Load resistance : More than $1k\Omega$)

Output Resolution

Approx. more than 1/2000

Digital Input

(Optional)

Number of Sub Output 2 points (DI1, DI2)

Input method

Non-voltage contact output

Function

SV selection, STOP/RUN, Auto/Manual, Alarm interlock reset,

Selectable

Communications

(Optional)

Communication method RS-485

Communication speed: 2400, 4800, 9600, 19200, BPS Protocol:

ANSI X3.28(1976) 2.5 A4 MODBUS-RTU

Bit format

Start bit :

•For MODBUS 8 bit only Data bit 7 or 8

Parity bit : Without, Odd or Even Stop bit :

1 or 2

Maximum connection : 31 units

Terminating resistor: External installation is necessary (120Ω 1/2W)

Buffer mode:

(Mode in which writing to EEPROM is not

performed for setting changes)

Waterproof/Dustproof

(Standard)

NEMA4X, IP66

Waterproof/Dustproof protection only effective from the front in panel mounted installation.

General Specifications

Supply Voltage
a) 90 to 264V AC (Including supply voltage variation)
[Rating: 100 to 240V AC] (50/60Hz selectable)
b) 21.6 to 26.4V AC (Including supply voltage variation)
[Rating: 24V AC] (50/60Hz selectable)
c) 21.6 to 26.4V DC (Ripple rate 10% p-p or less) [Rating:24VDC]

Power Consumption

RB900 : 6.0VA

RB100 : 108mA, RB400 : 141mA RB500 : 141mA, RB700 : 141mA 24V DC type:

RB900: 147mA

Rush Current

100 to 240V AC type: Less than 13.3A (240V), Less than 5.6A (100A) 24V AC type: Less than 16.3A 24V DC type: Less than 11.5A

Power Failure Effect
A power failure of 20m sec or less will not affect the control action.
• RB100, 24V AC/DC type: 10msec or less

Operating Environments: 0 to 50°C [32 to 122°F]
10 to 90% RH (Non condensing)
Absolute humidity: MAX. W.C 29.3g/m³ dry
air at 101.3kPa.

Memory Backup: Backed up by non-volatile memory

• Data retaining period: Approx. 10 years

• Number of writing: Approx. 1,000,000 times.
(Depending on storage and operating conditions.)

Net Weight

RB100 : Approx. 120g, RB400 : Approx. 185g, RB400 : Approx. 190g RB700 : Approx. 200g, RB900 : Approx. 250g

External Dimensions (W x H x D) RB100 RB400 48 x 48 x 60mm 48 x 96 x 60mm

RB500 RB700 96 x 48 x 60mm 72 x 72 x 60mm 96 x 96 x 63mm



RB 02E



Model and Suffix Code

Specifications RB500 (96 X 48mm, 1/8 DIN, Horizontal type) RB700 (72 X 72mm, 3/16 DIN) RB900 (96 X 96mm, 1/4 DIN) PID control with AT (Reverse action) PID control with AT (Chrect action) PID control with AT (Direct action) PID control with AT (Direct action) Heat/Cool PID control with AT (Direct action) Heat/Cool PID control with AT for extruder (Air cooling type) Heat/Cool PID control with AT for extruder (Water cooling type) W Input and range See Input range Code Table Output 1 (OUT1) See Output 1 Code Table (Control output) Output 2 (OUT2) See Output 2 Code Table (Control output or analog retransmission output (AO) Spewer Supply Digital output (DO) Digital output (DO) Do 2 points (DO1) DO 2 points (DO1) DO 2 points (DO1) DO 4 points (DO1) DO 4 points (DO1) DO 4 points (DO1) DO 4 points (DO1 to DO4) Not supplied For CTL-6-P-N (0 to 30A) 1 point For CTL-12-S56-10L-N (0 to 100A) 2 point * When digital output code is *N*, cannot be specified. For CTL-12-S56-10L-N (0 to 100A) 2 point * When digital output code is *N*, cannot be specified. RS-485 (ANSI/RKC standard protocol) R 4			Model and Suffix Code	
PID control with AT (Direct action) Heat/Cool PID control with AT Heat/Cool PID control with AT for extruder (Air cooling type) Heat/Cool PID control with AT for extruder (Water cooling type) W Input and range See Input range Code Table Control output		Specifications	RB400 (48 X 96mm, 1/8 DIN, Vertical type) RB500 (96 X 48mm, 1/8 DIN, Horizontal type) RB700 (72 X 72mm, 3/16 DIN) RB900 (96 X 96mm, 1/4 DIN)	1 2 3 4 5 6 7 8 9 10 11 12
③ Output 1 (OUT1) See Output 1 Code Table (Control output) ④ Output 2 (OUT2) Not supplied See Output 2 Code Table (Control output or analog retransmission output (AO) ⑤ Power Supply 24V AC/DC 100 to 240V AC ⑤ Digital output (DO) DO 1 points (DO1) 1 DO 2 points (DO1, DO2) 2 DO 4 points (DO1 to DO4) Available for RB400/900 only 1 Not supplied For CTL-6-P-N (0 to 30A) 1 point • When digital output code is "N", cannot be specified. For CTL-6-P-N (0 to 30A) 2 point • When digital output code is "N", cannot be specified. For CTL-6-P-N (0 to 30A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Sometimes of CTL-6-P-N (0 to 100A) 2 point • W			PID control with AT (Direct action) Heat/Cool PID control with AT Heat/Cool PID control with AT for extruder (Air cooling type) Heat/Cool PID control with AT for extruder (Water cooling type)	D G A W
② Output 2 (OUT2) Not supplied See Output 2 Code Table (Control output or analog retransmission output (AO) ⑤ Power Supply 24V AC/DC 100 to 240V AC ⑤ Digital output (DO) DO 1 points (DO1) ⑤ DO 2 points (DO1, DO2) DO 4 points (DO1 to DO4) Not supplied For CTL-6-P-N (0 to 30A) 1 point	_			
Solution Power Supply 24V AC/DC	<u>3</u>	Output 1 (OUT1)	See Output 1 Code Table (Control output)	
**3 Not supplied	4	Output 2 (OUT2) *1, *2	Not supplied See Output 2 Code Table (Control output or analog retransmission output (AO)	
Digital output (DO)	⑤	Power Supply		
For CTL-6-P-N (0 to 30A) 1 point • When digital output code is "N", cannot be specified. For CTL-12-S56-10L-N (0 to 100A) 1 point • When digital output code is "N", cannot be specified. For CTL-6-P-N (0 to 30A) 2 point • When digital output code is "N", cannot be specified. For CTL-12-S56-10L-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified. Not supplied RS-485 (ANSI/RKC standard protocol) S	6	Digital output	DO 1 points (DO1) DO 2 points (DO1, DO2)	1 1 1 1 1 1 1 1 1 1
RS-485 (ANSI/RKC standard protocol) 5	7	CT input	For CTL-6-P-N (0 to 30A) 1 point • When digital output code is "N", cannot be specified. For CTL-12-S56-10L-N (0 to 100A) 1 point • When digital output code is "N", cannot be specified. For CTL-6-P-N (0 to 30A) 2 point • When digital output code is "N", cannot be specified. • When digital output code is "N", cannot be specified. For CTL-12-S56-10L-N (0 to 100A) 2 point • When digital output code is "N", cannot be specified.	P
Digital input (DI) DI 2 points RS-485 (ANSI/RKC standard protocol) + DI 2 points RS-485 (MODBUS protocol) + DI 2 points • Available for RB400/900 only • Available for RB400/900 only	8	Communication/ Digital input (DI)	RS-485 (ANSI/RKC standard protocol) RS-485 (MODBUS protocol) DI 2 points RS-485 (ANSI/RKC standard protocol) + DI 2 points • Available for RB400/900 only	5
 Waterproof/ Dustproof Waterproof/Dustproof protection N 1 	9			
© Case color White case Black case	10		White case Black case	
Ouick start code (Default setting)	11)	Quick start code	No quick start code (Default setting)	N 1
② Instrument version Version symbol	12	Instrument version	1 71 /	Y

^{*1} When control method is selected for PID control (Code : F, D), output 2 is available for analog retransmission output.

Input range code table

Thermocouple	Temperat	Temperature Input Group (Field-programmable) DC Current • Voltage Group									Itage Group	
1 K 01 0 to 200°C K 02 0 to 400°C K 03 0 to 600°C K 04 0 to 800°C K 05 0 to 1000°C K 06 0 to 1000°C C 0 to 1000°C 0 to 1000°C C 0 to 1000°C 0 to 1000°C C 0 to 1000°C 0 to	Thermoc	nermocouple				RTD	RTD			(Field-programmable)		
K 02 0 to 400°C (JIS/IEC) S A2 0 to 3216°F D 02 -199.9 to +200.0°C 0 to 5V DC 4 01 -1999 to +9999 (Programmable) C C C C C C C C C	Input	Code	Range	Input	Code	Range	Input	Code	Range	Input	Code	Range
K 03 0 to 600°C K 04 0 to 800°C K 05 0 to 1000°C K 06 0 to 1200°C B A2 0 to 3308°F C D 06 0.0 to 50.0°C A to 200°C B 0.0 to 1000°C	1			S 2								
K 04 0 to 800°C K 05 0 to 1000°C K 06 0 to 1200°C J 05 0 to 1200°C K 06 0 to 1200°C K 06 0 to 1200°C B A1 800 to 3200°F B A2 0 to 3308°F D 06 0.0 to 50.0 C 0 to 2000 AD 07 100.0 to 100.0 C 07 101 Factory set value 1.0 to 2000 AD 07 100.0 to 100.0 C 07						0 to 3216°F						
K 105 0 to 1000°C (JIS/IEC) B A1 800 to 3200°F D 106 0.0 to 50.0°C 0 to 20mA DC 7 101 Factory set value 0.0 to 1200°C B A2 0 to 3308°F												(Programmable)
K 06 0 to 1200°C (JIS/IEC) B A2 0 to 3308°F D 06 0.0 to 50.0°C 4 to 20mA DC 8 01 :0.0 to 100.0	'			B								Factory act value
V 44 000 4 407000	1/			(JIS/IEC)								: 0.0 to 100.0
(S/IFC) N 41 -200 to +1372 to 1 E ()1 () to 8()()°C D 0/1 0.0 to 100.0 to 4 5 or current input connect is a 2500)				<u> </u>								
(olo/leo)	(JIS/IEC)			_ 1								
K 10 00 to 800 0°C D 00 D 00 to 300 0°C Shake resistor to the input terminals.							D4400					
K 143 100.0 to 1400.09C (JIS/IEC) 5 140 09C Widdel Code . RD 100-35				(JIS/IEC)						Model code	: KD100)-55
K 43 -199.9 to +400.0°C C C C C C C C C C	'						(JIS/IEC)					
K A2 0 to 1600°F N N 02 0 to 1300°C D A3 -199.9 to +200.0°F	'			N								
11.02 0.0 1000 0				(JIS/IEC)								
K C8 -100.0 to +752.0°F N A2 0 to 2372°F D A5 -199.9 to +300.0°F				(0.0/.20)				D A5				
1 J 01 0 to 200°C 1 T 02 -199.9 to +100.0°C D A6 0.0 to 100.0°F	1	J 01	0 to 200℃	1				D A6				
J '02 0 to 400℃ T '03 -100.0 to +200.0℃ D 'A7 0.0 to 200.0°F				' '	T ¦03			D¦A7	0.0 to 200.0°F			
J 03 0 to 600°C T T 05 -199.9 to +300.0°C D A8 0.0 to 400.0°F				T								
J 04 0 to 800°C (JIS/IEC) T 06 0.0 to 400.0°C D A9 0.0 to 500.0°F	'			(JIS/IFC)								
[1 0 0 to 1000°C 1 1 C7 0.0 to 600.0°F D B2 -199.9 to +900.0°F	J			(0.0/.20)								
US/IEC J O6 O to 1200°C T C8 -199.9 to +300.0°F P O1 -199.9 to +649.0°C												
7 5 15 -200 to +1200 c	(3.3)											
J '07 -199.9 to +300.0°C 2 W '01 0 to 2000°C P '03 -100.0 to +50.0°C J 'A1 0 to 800°F W5ReW26Re W '02 0 to 2320°C P '.04 -100.0 to +100.0°C	'			WEDOWINED 2								
	'						104400					
1 DO 000 1 01000 0 1 0000 0 1				(ASTIVI)								
	'			D			(JIS)					
D 2 P 102 0 to 1760°C A 144 0 to 2400°C P 108 0 to 200.0°C	D 2			1								
R 2 R 02 0 to 1769°C (NBS) A A1 0 to 2400°F P 08 0.0 to 200.0°C P 09 0.0 to 300.0°C				(NBS)								
*1 : Accuracy is not guaranteed for less than -100°C (-146°F) .				100°C / 146°		0 10 20041						

Output signal code table

Output 1 Code Table				
Output Type	Code			
Relay contact output	M			
Voltage pulse output	V			
0 to 5V DC	4			
0 to 10V DC	5			
1 to 5V DC	6			
0 to 20mA DC	7			
4 to 20mA DC	8			
Triac output	T			
Open collector output	D			

Output 2 Code Table							
Output Type			Output Type	Code	Remarks		
Relay contact output	(Cool side output)	M	Relay contact output (Event 3 [DO3] output)	Р	Only RB100		
Voltage pulse output			0 to 20mA DC (Analog retransmission output [AO])	R	Only PID control		
0 to 5V DC	(Cool side output)	4	4 to 20mA DC (Analog retransmission output [AO])	S	Only PID control		
0 to 10V DC	(Cool side output)	5	0 to 5V DC (Analog retransmission output [AO])	Х	Only PID control		
1 to 5V DC	(Cool side output)		0 to 10V DC (Analog retransmission output [AO])	Υ	Only PID control		
0 to 20mA DC	(Cool side output)		1 to 5V DC (Analog retransmission output [AO])	Z	Only PID control		
4 to 20mA DC	(Cool side output)						
Triac output	(Cool side output)						
Open collector output	(Cool side output)	D					

^{*2} On the RB100, the event 3 output function can be specified for output 2.

^{*3} The number of DO points is limited in some combinations of OUT1 and OUT2 (control output) types.

^{*2 :} Accuracy is not guaranteed for less than 400°C (752°F) for Input Type R, S, B, and W5Re/W26Re.

Maximum number of digital outputs (DO) by combinations of output (OUT1 and OUT2)

			OUT2 (Including transmission output)							
			No OUT2 output	M, T, D	(10 mA)	(20 mA)	Current output	Voltage output		
	*1	M, T, D	4	4	4	4	4	4		
		V (Load: 10 mA)	4	4	4	4	2	2		
	OUT1	V (Load: 20 mA)	4	4	4	2	2	2		
		Current output	4	4	2	2	2	2		
		Voltage output	4	4	2	2	2	2		

: Represents selection of digital outputs -DO3 and DO4 are not available.)

*1 When the instrument has two digital outputs (DO1 and DO2) and no OUT2 output, "V" type output (load: 40mA) can be specified for OUT1.



Quick Start Code

Quick start code 2 tells the factory to ship with each parameter preset to the values detailed as specified by the customer.
 Quick start code is not necessarily specified when ordering, unless the preset is requested.
 These parameters are software selectable items and can be re-programmed in the field via the manual.

Event Code Table (Programmable)


Specifications	Quick start code		-0				
Digital output 1 (DO1)	None	N					
(Event 1 type)	See event code table						
Digital output 2 (DO2)	None	N					
(Event 2 type)	See event code table						
Digital output 3 (DO3)	None	N					
(Event 3 type) *1	See event code table						
Digital output 4 (DO4)	None	N N					
(Event 4 type) *2	See event code table						
	None		Ν				
	SV1 to SV4 select		1				
Digital input (DI)	SV1/SV2 select + STOP/RUN		2				
Digital Input (DI)	SV1 to SV2 select + MANUAL/AUTO		3				
	SV1 to SV2 select + Alarm interlock reset		4				
	STOP/RUN + MANUAL/AUTO		5				
	STOP/RUN + Alarm interlock reset		6				
	MANUAL/AUTO + Alarm interlock reset		7				
*1. On the RR100, this can be specified when event 3 (Code : "P") is selected							


^{1:} On the RB100, this can be specified when event 3 (Code: "P") is selected in output 2.

Code	Event Type								
Α	Deviation High								
В	Deviation Low								
С	Deviation High/Low (Common high/low setting)								
D	Band (Common high/low setting)								
E	Deviation High with Hold								
F	Deviation Low with Hold								
G	Deviation High/Low with Hold (Common high/low setting)								
Н	Process High								
J	Process Low								
K	Process High with Hold								
L	Process Low with Hold								
Q	Deviation High with Alarm Re-hold								
R	Deviation Low with Alarm Re-hold								
Т	Deviation High/Low with Re-Hold (Common high/low setting)								
U	Band (Individual high and low settings)								
V	Set value High								
W	Set value Low								
X	Deviation High/Low (Individual high and low settings)								
Υ	Deviation High/Low with Alarm Hold (Individual high and low settings)								
Z	Deviation High/Low with Alarm Re-Hold (Individual high and low settings)								
1	Heater break alarm (HBA)								
2	Loop break alarm								
3	FAIL								
4	RUN status								
5	Output of the communication monitoring result								

Example of Model Code and Quick start code 3

Specifications






RB_02E 6

^{*2:} On the RB100, this is fixed at "none".



RB500

External Dimensions



Panel Cutout 45 45^{+0.6}

(Panel thickness must be between 1 to 10mm)

Panel Cutout


(Close horizontal mounting) * Up to 6 units

Unit: mm



n : Number of controllers (2=<n=<6)
• Waterproof/dustproof is not available for close horizontal mounting

(Close horizontal mounting) * Up to 6 units




n : Number of controllers (2=<n=<6)

· Waterproof/dustproof is not available for close horizontal mounting.

RB400 The mounting brackets can be attached on the sides of the controller. However, to make the controller waterproof and dustproof, attach the mounting brackets to the top and bottom. (2 places).


The mounting brackets can be attached on the sides of the controller. However, to make the controller waterproof and dustproof, attach the mounting brackets to the top and bottom.



25 (Panel thickness must be between 1 to 10mm)

8

*1 : Case rubber packing (optional) [Waterproof/dustproof]



*1 : Case rubber packing (optional) [Waterproof/dustproof] 1.0 *1

92^{+0.8}

RB700 Panel Cutout 67.8 82.2 68^{+0.7} 25 1.0*1

1.0*1


*1 : Case rubber packing (optional) [Waterproof/dustproof]

90

(Close vertical mounting) Up to 6 units I = 48Xn - 3

(2 = < n = < 6)Waterproof/dustproof is not available for close horizontal mounting.


(Close horizontal mounting)




n : Number of controllers

(2=<n=<6)
• Waterproof/dustproof is not available for close horizontal mounting

RB900 The mounting brackets can be attached on the sides of the controller. However, to make the controller waterproof and dustproof, attach the mounting brackets to the top and bottom. 91.8 96 106.1






n: Number of controllers

· Waterproof/dustproof is not available for close horizontal mounting.




Rear Terminals








Accessory







Front Cover

RB900

Model Code:



RB400/500



Model Code: Model Code: KRB400-36 KRB100-36A

